

BlackBerry 7100v™ from Vodafone

Getting Started Guide



©2004 Research In Motion Limited. All Rights Reserved. The BlackBerry and RIM families of related marks, images, and symbols are the exclusive properties of, and trademarks of, Research In Motion Limited (RIM). All other brands and marks are the properties of their respective owners. IBM, Lotus, Domino, and Lotus Notes are trademarks of International Business Machines Corporation in the United States, other countries, or both. Intel is a registered trademark of Intel Corporation or its subsidiaries in the United States and other countries. Microsoft, Outlook, and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Research In Motion Limited is under license. Vodafone is a registered trademark of Vodafone and may have protection under the laws of other countries. There are no warranties, express or implied, with respect to the contents of this document, and all information provided herein is provided "as is". In no event shall RIM or its affiliates be liable to any party for any direct, indirect, special, or consequential damages in connection with your use of this document, including, without limitation, loss of business revenue or earnings, lost data, damages caused by delays, lost profits, or a failure to realize expected savings, even if RIM was expressly advised of the possibility of such damages. RIM reserves the right to periodically change information that is contained in this document; however, RIM makes no commitment to provide any such changes in a timely manner or at all. Your handheld might vary from the depictions on this document.

Published in XXXXX.
PRINTSPEC-005
MAT-07532-001 rev.002
Model number: RAQ41GW



How do I navigate?

Roll the trackwheel to move the cursor and highlight items on the screen.

Click (press) the trackwheel to open the menu or select items.

Press the Escape button to exit a screen, cancel an action, or go back one page in the browser.

How do I type?

To type using SureType™ technology, press each letter key only once until you have typed an entire word. The letters on the screen change automatically until a word is formed.



To switch to the multi-tap input method, in a text field, hold the * key. Press a key once for the first letter and twice for the second.

Tips



Phone

- Open the phone screen or make a phone call Press
- End a call Press
- Turn mute on and off during a phone call Press
- Change the volume during a call Roll the trackwheel
- Dial a letter in a phone number Hold + press the letter (once for the first letter, twice for the second, using the multi-tap method)
- Redial a number Press twice
- Call voice mail Hold
- Assign speed dial to a number Hold the number > Type a phone number
- Type a phone number[] extension[] Press > Type the extension number
- Turn speakerphone on and off during a call Press



Browser

- Go back one page Press the **Escape** button
- Exit the browser Hold the **Escape** button
- Go to next page in history Press
- Go to previous page in history Press
- Switch between normal and full-screen mode Press
- Page down Press
- Stop a web page from loading Press the **Escape** button
- Go to a specific web page Press



Messages

- Compose from the messages list Press
- Reply to sender Press
- Reply to all Press
- Forward a message Press
- Go to the next message Press
- Go to the previous message Press
- View received messages Press +
- View SMS messages Press +
- View voice mail messages Press +
- Page up in an open message Press
- Page down in an open message Press



Calendar*

- Go to the next day, week, or month Press
- Go to the previous day, week, or month Press
- Schedule an appointment Press

- Move the cursor horizontally in week view Hold + roll the trackwheel
- Move the cursor vertically in week view Hold + roll the trackwheel

*In the calendar options, set the **Enable Quick Entry** field to **No** to use these shortcuts in Day format.

Note: The arrangement of letters on your handheld keypad might vary slightly from the depictions on this document.